

PRODUCT INFORMATION BROCHURE

E*STAR REMOTE BLASTER



E*STAR Remote Blaster is a

multipurpose device designed to work with E*STAR detonators. The main functions of the E*STAR Remote Blaster are to verify, charge & fire all detonators in all branches. It is possible to fire up to 1,600 E*STAR detonators per blast. If connected with second E*STAR Remote Blaster through E*STAR Blaster Sync module in master-slave mode it is possible to fire up to 3,200 E*STAR detonators per blast. E*STAR Remote Blaster is designed for using with E*STAR Remote.

PRODUCT OVERVIEW

PROPERTIES

- Verify all detonators
- Change detonators delay
- Charge detonators capacitors
- Fire detonators
- Transfer data from Logger / Loggers
- Transfer data to PC for post processing

BENEFITS

- All detonators verified prior firing
- 30 minutes ready to fire time
- Data download after firing
- Large buttons suitable for use with gloves
- Water resistant
- E★STAR Remote connectivity

STANDARD TECHNICAL DESCRIPTION

Name / Type	E*STAR Remote Blaster / DBM1600-2-RC
Weight	5,300 g
Size	270 x 250 x 180 mm
Case	ABS plastic
Battery	9 x NiMH (rechargeable), built-in
Charging	Mains charger (100 – 240 V; 50 – 60 Hz) Car charger (11 – 16 V system)
Operation voltage	42.5 V
Operation current	0.55 mA (programing), 150 mA (verification)
Temperature range for application	From -30 °C to +60 °C in temperatures under -20 °C slower display reaction
Storage condition	From 0 °C to +40 °C R.H. max. 80%
Firing capabilities	Maximum 1,600 detonators (normal mode, single Blasting Machine) Maximum 3,200 detonators (master-slave mode, two Blasting Machines)

Contact your local Austin Powder representative for further information.

AUSTIN POWDER

Disclaimer of Warranties and Limitations of Liabilities

Any information contained herein is based on the manufacturer's standard procedures in use at the time of publication. Any specifications, test values and other data is solely preliminary information and not guaranteed. Actual results may differ during field use. Neither manufacturer nor seller will be responsible whatsoever for any losses or damages resulting from the use or reliance upon any information set forth herein.

It is solely the responsibility of the product user to determine the safe conditions for use of the products referred to herein. Use of any products by a user is at the user's sole risk. To the maximum extent permitted by law, manufacturer and seller specifically disclaim all warranties including implied warranties of merchantability or fitness for a particular purpose.



Our Mission is to improve the world we live in through the safe and responsible use of explosives.

AUSTIN POWDER SWEDEN AB, Kulvägen 5H, 703 69 Örebro, Sweden www.austinpowder.se | Email: post@austinpowder.se | Phone: 070 518 16 00